

PLASMA PARTS/TORCHES-TRAFIMET (Compatible)

TRAFIMET® TW-A101x8-HT-CC



TRAFIMET® TW-A101x8-MT-CC



TRAFIMET® A90/A101



TRAFIMET® S75 / S105



PART NO

REFERENCE


1001	TW-A101x8-HT-CC	Hand Torch 8M Ctrl Conn
1002	TW-A101x8-MT-CC	Auto Torch 8M Ctrl Conn
1003	TR-TH-A101-H	Torch Head
1006	TR-A101-FH	Front Handle
111	TR-EL-0101-C	PR0101 (Electrode)
112	TR-T-0101-09-C	PD0101-09 (Tip 0.9 mm)
112	TR-T-0101-11-C	PD0101-11 (Tip 1.0 mm)
112	TR-T-0101-12-C	PD0101-12 (Tip 1.2 mm)
112	TR-T-0101-14-C	PD0101-14 (Tip 1.4 mm)
112	TR-T-0101-16-C	PD0101-16 (Tip 1.6 mm)
112	TR-T-0101-18-C	PD0101-18 (Tip 1.8 mm)
181	TR-SR-0101	PE0101 (Swirl Ring)
182	TR-RC-0109	PC0109 (Retaining Cap)
183	TR-SS-0011	CV0011 (Stand Off Spring)
184	TR-FI-A90	Front Insulator(Vespel)

PART NO

REFERENCE

271	TR-EL-0117-C	PR0117 (Electrode)(S75)
272	TR-T-0114-10-C	PD0114-10 (Tip 1.0 mm)(S75)
272	TR-T-0114-12-C	PD0114-12 (Tip 1.2 mm)(S75)
511	TR-T-0119-14	PD0119-14 (S105)
274	TR-SR-0112-C	PE0112 (Swirl Ring)(S75)
512	TR-RC-0118	PC0118 (Retaining Cap)
514	TR-RC-0114	PC0114 (Retaining Cap)
513	TR-CV-0021	CV0021 (Carriage)

TRAFIMET® S45



TRAFIMET® A151



PART NO

REFERENCE

1004	TW-S45x6-E	Torch 6M
1005	TR-S45-TH	Torch Head
901	TR-EL-0110	PR0110 (Electrode)
902	TR-T-0116-06	PD0116-06 (Tip)
	TR-T-0116-09	PD0116-09 (Tip)
903	TR-SR-0106	PE0106 (Swirl Ring)
904	TR-RC-0116	PC0116 (Retaining Cap)

PART NO

REFERENCE

301	TR-EL-0111	PR0111 (Electrode)
302	TR-T-0109-14	PD0109-14 (Tip 1.4 mm)
303	TR-T-0109-16	PD0109-16 (Tip 1.6 mm)
304	TR-T-0109-18	PD0109-18 (Tip 1.8 mm)
305	TR-T-0109-30	PD0109-30 (Tip 3.0 mm)
306	TR-SR-0103	PE0103 (Swirl Ring)
307	TR-RC-0120	PC0120 (Retaining Cap)
308	TR-GD-0563	FH0563 (Gas Diffusor)