


TIG HANDLE PARTS


TORCH HEAD HANDLE



PART NO

FH-17T
WP-17 Torch Handle
With switch etc

TORCH HEAD HANDLE



PART NO

FH-26T
WP-26 Torch Handle
With switch etc

TORCH HEAD HANDLE



PART NO

FH-17-T2-BL / FH-26-T2-BL
Front Handle WP-17/26 - Blue

FH-17-T2-RD / FH-26-T2-RD
Front Handle WP-17/26 - Red

TORCH HEAD HANDLE



PART NO

1. FH-17-T3-BY / FH-26-T3-BY
WP-17/26 Torch Handle Kit
With Switch, Grommet &
Screws etc – Black/Yellow

2. SW-T3-Y Trigger Switch

TORCH HEAD HANDLE



PART NO

1. FH-17-T3
Front Handle WP-17 –
Blue/Yellow

7. FH-17-T3-R
Front Handle WP-17 –
Black/Red

TORCH HEAD HANDLE



PART NO

1. FH-26-T3
Front Handle WP-26 -
Blue/Yellow

7. FH-26-T3-R
Front Handle WP-26 -
Black/Red

TORCH HEAD HANDLE



PART NO

FH-G-A1
Front Handle
(Blue/Blk) for WP-9/26
with Standard Switch

TORCH HEAD HANDLE



PART NO

FH-G-A2
Front Handle
(Blue/Blk) for WP-9/26
with 2 Way Switch
Mechanism

TORCH HEAD HANDLE



PART NO

FH-G-A3V
Front Handle (Blue/Blk)
for WP-9/26 with
Vertical Potentiometer
Switch (5K Ohm)

FH-G-A3V(10)
Potentiometer Switch
(10K Ohm)

TORCH HEAD HANDLE



PART NO

FH-G-A4H
Front Handle (Blue/Blk) for
WP-9/26 with Horizontal
Potentiometer Switch
(5K Ohm)

FH-G-A4H(10)
Front Handle (Blue/Blk) for
WP-9/26 with Horizontal
Potentiometer Switch
(10K Ohm)